

Configuration for optional device

Note

- The options can be connected each other.
- MK-732 must be connected for connecting PI-502.
- The combination except as mentioned in the following is prohibited.

[Coupling combination of the main body and the paper feed option](#)

[Coupling combination of the main body and the finisher option](#)

[Options that connect to the external AC power supply](#)

Coupling combination of the main body and the paper feed option

Main body	Op.1	Op.2
Main body	-	-
Main body	PF-709	-
Main body	LU-414	-
Main body	LU-415	-
Main body	MB-507	LU-414
Main body	MB-507	LU-415

Coupling combination of the main body and the finisher option

Op.2	Op.1	Main body
FS-532*1	-	Main body
OT-512	-	Main body
OT-507	-	Main body
FS-532*1	ZU-608	Main body
OT-512	ZU-608	Main body

*1: Only W*6 or later for the FS-532. In addition, the SD-510, the PK-525, or the PI-502 + MK-732 can be connected arbitrarily to the FS-532.

Options that connect to the external AC power supply

Type	Target options
MainBody	MainBody
Finisher option	ZU-608